

**Electrolux**



**ExtraStrong Clean  
for oven**



**ExtraStrong Rinse  
for oven**



**Rapid Grease  
for griddle and tops**

**The best “formula,”**  
to take care of your appliances

 **Electrolux**

Service



# ExtraStrong Clean *for oven*



The cleaning agent developed by Electrolux will guarantee the best results for keeping your oven clean and hygienic.

The particular chemical composition of **ExtraStrong Clean for oven** effectively removes the most stubborn, greasy cooking residues, saving time and reducing labour costs.

Thanks to its liquid formulation, **ExtraStrong Clean for oven** oven is easily dissolved in hard or soft water.

## Usage

### For professional use only!

Use only on ovens equipped with integrated cleaning systems.

Do not mix with other products.

Do not use on other surfaces.

Do not apply directly on the oven's interior.

See label for additional information.

## Instructions

1. Wear safety gloves and glasses.
2. Pour **ExtraStrong Clean for oven** oven using the special dispenser into the integrated cleaning system.
3. Select the desired cleaning cycle and press Start.

## Storage

Keep the container closed and in good conditions.

Store at a temperature between 0°C and 40°C.



4 x 5 lt containers

**Code 0S1192**



# ExtraStrong Rinse *for oven*



From Electrolux research, this is the ideal rinse aid to keep your oven dry and sparkling.

**ExtraStrong Rinse for oven** keeps your ovens surfaces clean and sparkling, while making them dry faster, saving time.

Thanks to its liquid formulation, **ExtraStrong Rinse for oven** is easily dissolved in water, whether hard or soft. For best results, use regularly.

## Usage

### For professional use only!

Use only on ovens equipped with integrated cleaning system.

Do not mix with other products.

Do not use on other surfaces.

Do not apply directly on the ovens interior.

See label for additional information.

## Instructions

1. Wear safety gloves and glasses.
2. Pour **ExtraStrong Rinse for oven** using the special dispenser into the integrated cleaning systems.
3. Select the desired cleaning cycle and press Start.

## Storage

Keep the container closed and in good conditions.

Store at a temperature between 0°C and 40°C.



4 x 5 lt containers  
**Code 0S1193**



# Rapid Grease



The cleaning solution for cooking plates from Electrolux that works at high temperature.

**Rapid Grease** can be used directly on cooking plates and griddles without having to wait for it to cool. Thanks to its special composition, **Rapid Grease** is ideal for cleaning stubborn cooking deposits and greasy residues.

**Rapid Grease** even resolves the typical problems of cooking with different kinds of food (for example, fish and meat), providing flexibility in the kitchen.

## Usage

### For professional use only!

Do not mix or dilute with other products.  
See label for additional information.

## Instructions

1. Turn off the appliance and remove the food residues from the surface to clean.
2. Apply a layer of *undiluted* **Rapid Grease** on the entire surface while still hot (max. 175°C), using a scrub pad, the product dispenser.
3. Wait a few minutes for the product to work.
4. Remove any remaining residues using the scraper and clean the surface with the scrub pad. Rinse the surface and dry the cooking plate using a damp cloth.  
*(Accessories - scrub pad / scraper / product dispenser must be ordered separately)*

## Storage

Keep the container closed and in good conditions.  
Store at a temperature between 0°C and 50°C.



4 x 1 lt containers  
**Code 0S1195**

**Electrolux Professional SpA**

Viale Treviso, 15 - 33170 Pordenone - Italy - Tel. (+39) 0434 3801

[www.electrolux.com/foodservice](http://www.electrolux.com/foodservice)

Share more of our thinking at [www.electrolux.com](http://www.electrolux.com)

